

## WARRANTY & SERVICE

We guarantee the unit to be free from defects in material or workmanship for a period of one (1) year from the date of purchase.

Operating this unit with an adapter other than the one supplied or any attempts made to service or modify the unit, will VOID THE WARRANTY.

For your convenience, please record the complete model number and the date of purchase below, and attach your receipt as proof of purchase.

Attach your purchase receipt here

Serial No.: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

Name and address of Purchaser: \_\_\_\_\_


Telephone: \_\_\_\_\_

## Questions or Concerns?

Please visit our website at [www.invisipure.com](http://www.invisipure.com) or contact us at [support@invisipure.com](mailto:support@invisipure.com)



# InvisiPure HydroWave Dehumidifier



Model IP-DH800

If you have any questions, please email us at [Support@InvisiPure.com](mailto:Support@InvisiPure.com) or call us at 818-787-1188 Monday – Friday 9AM-5PM Pacific time for immediate assistance.

## IMPORTANT SAFETY INSTRUCTIONS

### PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING.



This product should be used only in accordance with the specifications outlined in this manual. Usage other than what has been specified here may result in serious injury.

When using electrical appliances, basic safety precautions should always be followed.

1. Do not operate the unit with a damaged cord or plug, after it malfunctions or has been dropped or damaged in any way. Return to an authorized service facility for examination and repair.
2. This unit should always be kept in an upright position to avoid any damage. The appliance must be placed on a flat, level surface during operation.
3. Check the household voltage to ensure it matches the units rated specification before operating.
4. Ensure that the air inlets and outlets are not blocked or covered.
5. Do not place the unit too close to curtains or other objects – minimum 16”.
6. Never place anything on top of the unit and do not cover with any kind of material while in use.
7. This product is intended for domestic and light office use ONLY and not for commercial, industrial or outdoor use.
8. To protect against electrical shocks, do not immerse unit, plug or cord in water, or spray with liquids.
9. Never unplug the power cord with the unit turn on.
10. Always unplug the unit when not in use or moving location. To disconnect from the power supply, grip the plug and pull from the power socket. Never pull by the cord.
11. Always empty the water tank before storing the unit away.
12. Close supervision is necessary when any appliance is used by or near children and pets.
13. Do not run power cord under carpeting, or cover with rugs or runners. Arrange the cord away from areas where it may be tripped over.
14. Never operate or store the unit in direct sunlight.
15. To repair the unit, take it to a qualified service engineer. Repairs carried out by unqualified people may cause damage to the unit or injury to persons or property and void the warranty.
16. Wherever possible, avoid the use of an extension cable as they may overheat and cause a risk of fire. Only use an extension cord after ensuring it is in perfect condition.
17. Do not tamper with the unit. Tampering with the unit will void the warranty.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

## SAVE AND READ THESE IMPORTANT SAFETY INSTRUCTIONS

### Features

- Quiet operation
- Innovative compact design for easy portability
- Simple one-button control
- Night light
- Transparent tank for water visibility
- Water tank full warning when light turns red
- Auto switch off when water tank is full or removed
- Auto overheat protection

## PRODUCT SPECIFICATIONS AND PARTS

### SPECIFICATIONS

**MODEL NUMBER:** IP-DH800

**POWER SUPPLY:** 100V-240V AC, 60Hz

**POWER CONSUMPTION:** 75W


**TANK CAPACITY:** 2L

**DEHUMIDIFYING RATE:** Approximately 600-800ml/day (at 86 F and 80% Relative Humidity)

**DIMENSIONS:** 9.8” x 6.1” x 13.9” (LxWxH)

**Weight:** 5.7 lbs

## PARTS



1. Humidity sensor
2. Indicator (When powered on, the indicator turns blue. When tank is full, the unit will automatically turn off and the indicator will turn red)
3. Air outlet
4. Handle
5. ON/OFF button
6. Filter
7. Air intake
8. Screw (Unscrew this to clean the filter)
9. Water tank cover
10. Tank
11. Power Cord

## OPERATING INSTRUCTIONS

Plug in the power supply into a 100-240V AC electrical outlet.

- Please use an AC electrical outlet as stated on the label. A higher voltage may lead to malfunction causing fire or electric shock.
- Do not use the unit when the power cord or plug is broken, or the socket is loose.
- Do not turn on the unit when the water tank is full or when the unit is upside down.

## CONTROL PANEL




- Press the "On/Off" button (5) to "On" position, the dehumidifier will begin to operate. The blue LED indicator will be turn on. Listen and feel for the air blowing from dry air outlet (3).
- Press the "On/Off" button (5) to "Off" position, the dehumidifier will turn off.

## When tank is full of water


- The dehumidifier will stop when water tank is full and the red indicator will turn on. To continue using the unit, remove the water tank, empty it, and replace the water tank into the unit, as shown in the diagram below.

## WARNING

- Do not re-use or consume the water collected in the tank as it may contain germs, bacteria, fungi, and other microorganisms.



- Attach a hose to the tank for continuous drainage and continuous usage.




## MAINTENANCE INSTRUCTIONS

### CLEANING THE UNIT

Before cleaning the unit, turn the unit off and unplug it from the power socket to prevent electric shock and accidents. Wait until the unit has cooled down before unscrewing the screw for cleaning.

**Clean the unit:** Use a soft cloth to clean the surface of the unit, and a cotton swab to wipe the dust from the grill of the air intake and air outlet.

**Clean the Filter:** Clean the filter approximately every 6 months. (Every 3 months if the air quality is poor). To clean the filter, unscrew the screw to take out the filter, and then use water to wash it.



### MAINTAINING THE EXTERIOR OF THE UNIT

Use a soft cloth to wipe the outside of the unit. Clean only the exterior of the unit. Attempting to clean the inside of the unit may cause electric shock.

### MAINTAINING THE WATER TANK

After emptying the tank, clean the water tank and water tank cover under running water. Do not re-use or consume the water collected in the tank as it may contain germs, bacteria, fungi, and microorganisms.

**PLEASE NOTE!** Do not use solvents, gasoline, xylene, or talcum powder to clean the unit or water tank as this may cause deterioration or corrosion.

## STORAGE INSTRUCTIONS

If the unit will not be used for a long time:

1. Empty and clean the water tank. Wipe it dry with a clean, dry cloth, and reinstall it into the unit.
2. Pack the dehumidifier into a box or its original packaging to avoid dust from collecting on the unit.

Store in a cool and dry place.

## TROUBLESHOOTING GUIDE

- When troubleshooting your device, please refer to the following ways to remedy.
- If problem still occurs please contact the retailer you purchased the item from.

Problem	Probable Cause	Solution
Unit not powering on	Power cable not plugged in	Plug in the power cord
	Household circuit breaker	Reset your circuit breaker. If necessary, contact a licensed electrician.
	Unit is damaged or in need of repair	Stop operating and unplug the power source. Contact Customer Service for assistance.
	The water tank is full or the tank is not put in correctly.	Empty the water tank and put it back, or reinstall the tank correctly.
No dehumidification / No air come out from air outlet.	Fans have overheated causing the unit to stop operating.	The unit will start working automatically when the fan has cooled down.
	Air inlet or air outlet is blocked.	Remove any blockage from the air inlet or outlet.
Too Noisy	Unit is not on a stable surface.	Move the unit to a stable, flat surface.